


This Book Is a Companion Study Guide to the Online Course:



The course is free to all InterNACHI members.

Upon successfully completing the online course and passing the final exam, you will receive a Certificate of Completion and be able to:

- understand the major systems and components of a home;
- be able to inspect the foundation and framing components;
- find major structural defects; and
- describe observed indications of structural defects and their implications.

Take the online course at www.nachi.org/structuralcoursereleased2007

Structural Issues for Home Inspectors

The purpose of this publication is to help prepare the home inspector in the proper methods of observing and reporting on the structural components and their condition in a residential dwelling.

This is not an engineering manual, nor does it provide an inspector with the means to conduct a structural evaluation, as that is a process that typically requires the involvement of a licensed professional engineer or architect.

This book is also a handy, on-the-job reference manual, as well as a study guide for InterNACHI's related online course and final exam.

To order additional training books, visit www.InspectorOutlet.com

Authors:

Joe Farsetta, Chairman, InterNACHI Ethics Committee

Nick Gromicko, Founder, International Association of Certified Home Inspectors

Graphics:

Lisaira Vega, Levi Nelson, Jackson Tupper & Erica Saurey

Editor:

Kate Tarasenko / Crimea River

Layout & Design:

Jessica Langer



Copyright © 2015 International Association of Certified Home Inspectors, Inc.

All rights reserved.

The text of this publication, or any part thereof, may not be reproduced in any manner whatsoever without permission in writing from the authors.

www.NACHI.org

Table of Contents

Introduction	4	What to Look for Inside	20
Observe and Report	4	Roofing Structure and Attic	20
What Inspectors Need to Know	5	Basement and Crawlspace	22
Common Structural Terms	5	Floors	25
Common Foundation Types	8	Walls and Ceilings	28
Common Framing Structures	9	Windows, Doors and Moldings	29
Inspector Safety	10	Quiz #3	30
Quiz #1	11	The Report	31
What to Look for Outside	12	Report Writing	31
Property Lot	12	Conclusion	35
Exterior	13	Appendix I: Answer Keys	36
Decks and Porches	16	Answer Key to Quiz #1	36
Roof	17	Answer Key to Quiz #2	36
Quiz #2	19	Answer Key to Quiz #3	36

Introduction

Observe and Report

The structural portion of a home inspection is perhaps the single most important part. A house's structural integrity is often the issue of the greatest interest to home-buying clients. If the home is structurally unsound, not much else matters. This is why it's critical for the inspector to be competent in his ability to observe and report on what he sees during the structural portion of a home inspection.

But it isn't enough to simply look at the foundation and framing elements. Almost every part of a home reveals what's going on with its structure.

This guide helps improve the home inspector's awareness of structural defects, helps him avoid misdiagnosing problems, and defines his role in performing the structural portion of a home inspection. This book assumes that the reader already has a basic understanding of the structural components of a home.

Reporting structural observations is part of a home inspector's job. Offering a definitive determination as to the cause of any defects or anomalies is not. So, remember: Home inspectors are barred from providing engineering services. The job of the home inspector is to OBSERVE and REPORT. This publication is designed to help you do just that.

What Inspectors Need to Know

Common Structural Terms

Bearing Wall

A bearing wall, or a load-bearing wall, is designed to carry the weight of structural components above, through itself, and to the supporting components below. Removal of or modification to bearing walls without specific design considerations can lead to loss of structural integrity of the dwelling. Sometimes, the structural weakness is seen almost immediately. In other cases, the weakness is discovered only over time.

Beam

This is a horizontally placed wooden, steel or engineered member which supports floor framing members. It is a primary support member, and it's often supported by wooden or steel columns (or posts), exterior walls, or foundational elements.

Corner Post

This describes an assembly of perhaps three or even four vertical studs nailed together tightly to make up a corner framing element in a dwelling.


Cripple

This describes a grouping of short studs commonly found over (or sometimes below) openings, such as for windows and doors, where a full-length stud could not fit.

Footing

Typically seen at the bottom of the foundation or stem walls, the footing is generally made of poured reinforced concrete. Often wider than the foundation wall, the footing bears the full weight of the dwelling. In some instances when the soil is not completely compacted or is wet, a spread footing is designed and installed.

A spread footing is wider than normal. Footings can be affected by soil conditions, water intrusion, and soil erosion. Improperly supported footings can crack and cause a host of structural problems, starting at the foundation wall and extending throughout the dwelling. Remember that in some newer foundation configurations, footings are not required. Only time will tell how well these homes will fare. A no-footing installation is most typically seen with pre-cast concrete foundation assemblies, where tamped gravel supports the load transferred through the foundation walls.



Header

Typically, a header is a horizontally placed wooden framing member that is made to support the load when an opening is made in a load-bearing wall. Headers are usually installed above windows and exterior doors, or wherever an opening is made in an interior load-bearing partition.

Jack Stud

A jack stud is a wooden member or stud placed at the sides of an opening in a load-bearing partition, and designed to support a header assembly above. Jack studs are sometimes called trimmers. The header is supported by a jack stud at each end. Jacks fit under each end of a header, and they transfer the load that the header carries down to the bottom plate and the framing beneath. Nailed to the jacks are full-height studs called king studs; they support the assembly between the plates. Sometimes jacks must be doubled on wide openings so there's enough supporting surface for the header to bear on. Jacks can be replaced with a steel header hanger attached to the king stud.

Joist

These members are typically made of dimensional lumber, although some products (sometimes called TJIs, the abbreviation for the manufacturer Truss Joist International) are also used. The purpose of the joist is to provide a nailing and support system for the floor sheathing and for the floor itself. The joist supports the live and dead loads placed on the floor assembly. TJIs (or the equivalent) are like mini wooden I-beams, with 2x2 square stock on the top and bottom (chords), and plywood or oriented strand board (OSB) between the two. Attic or ceiling joists are used to provide floor support in attic spaces, and also help prevent the roof rafters from collapsing downward and pushing outward.

Pier

A pier is a sturdy point, typically at or below ground level, and generally constructed of concrete or a similar material, which supports a point load transferred from above. An example of this would be a pier installed below grade and covered by a concrete basement slab, on top of which rests a steel lally column supporting a wooden girder assembly.

Post

A post is a vertical member which may be made of steel, concrete, wood or masonry materials. It is designed to carry a point load vertically downward onto a pier or block.

Rafter

This is a wooden framing member extending from the ridge to beyond the top plate of an exterior wall, or serving as a connecting point between two sloping sections of the roof structure. Though this is the most common description, there are other named rafters that are installed in a slightly different manner. For instance, a jack rafter (short) may not extend to the top plate but may connect a variety of structural roofing components.

Ridge

Simply put, the ridge (or ridge beam) is installed at the intersection of roof rafters at their uppermost point. Ridge beams are typically made of wooden components. Be advised that not all roof structures require a ridge beam. On high sloping roofs, the ridge beam may be comprised of thin materials used only as a nailing point or spacer. This may be seen where no horizontal support is needed. On lower sloping roofs, the ridge actually carries a load and should be comprised of properly sized materials suitable for the purpose.

Roof Truss

A roof truss is a pre-engineered assembly of smaller individual framing components attached together and in a design suited to provide greater support and economy, as well as a faster installation time. It takes the place of rafters, attic (or ceiling) joists, and ridge beams, and is hoisted and nailed in place, forming the entire roof and attic structure. A roof truss spans the distance between exterior walls and requires no additional support. It is designed to take the guesswork out of field-framing for the connecting points for intricate or multiple rooflines, tray and cathedral ceilings, roof penetrations, etc.

Sheathing

This describes the outer skin of the dwelling. Sheathing is attached to the outside of walls and roof assemblies. It can be comprised of fibrous materials, such as Celotex®, backer board, or other materials in older homes, plywood, particleboard, planking or OSB, among other materials. Sheathing on roofs may also be referred to as roof decking.

Sill Plate

The first course of horizontal lumber placed on top of and attached to the foundation wall is known as the sill plate.

Slope

Slope is the incline of the roof expressed as a ratio of the vertical rise to the horizontal run, where the run is some portion of the span. This ratio is always expressed as inches per foot.

Slope Ratio

A roof that rises 4 inches for every 1 foot or 12 inches of run is said to have a “4 in 12” slope. If the rise is 6 inches for every 12 inches of run, then the roof slope is “6 in 12.”

The slope can be expressed numerically as a ratio. The slope ratio represents a certain amount of vertical rise for every 12 inches of horizontal run. For example, a “4 in 12” slope can be expressed as the ratio of 4:12. A “6 in 12” slope is expressed as 6:12.

Pitch

Pitch is the incline of the roof expressed as a fraction derived by dividing the rise by the span, where the roof span is the distance between the outside of one wall's top plate to another.

Sole Plate

In platform framing, this is the first course of horizontally placed lumber that goes on top of the sub-flooring material. It comprises the bottom of exterior walls and interior partitions where vertically positioned studs are attached.

Sub-Floor

A sub-floor is comprised of materials (usually plywood, OSB or planking) which are attached to joists and make up the top structural portion of the platform assembly on which occupants walk.

For more inspection-related glossary terms, visit: www.nachi.org/glossary


Common Foundation Types

Slab-on-Grade Foundation

A slab-on-grade foundation is a type of foundation consisting of a structural concrete slab poured directly on the grade. No accessible space exists in slab-on-grade construction. Slab-on-grade foundations are popular in areas where there is a high water table.

Crawlspace

A crawlspace is an accessible space between the ground and the bottom of the first floor of a home.



Full Basement

A full basement creates an accessible space between the ground and the bottom of the first floor of a home. Full basements are popular predominantly in cold climates where the footer needs to be below the frost line.


Pier

Pier foundations, like slab-on-grade foundations, are typically installed in areas that do not have the proper type of soil to support a full basement foundation.

Pre-Cast

Pre-cast wall sections are cast in a factory and shipped to the construction site. Sections are then lifted into place on a simple gravel footing and bolted together. The wall sections are then sealed.

Common Framing Structures



There are two common styles of wood framing: balloon and platform. The main difference between balloon and platform framing is apparent at the floor lines. The balloon wall studs extend from the sill of the foundation all the way to the top plate of the second floor. The platform framed wall, on the other hand, is independent for each floor.

Balloon Framing

Balloon framing is an older method of wood framing that utilizes long, continuous framing members (studs) that run from sill to eaves, with intermediate floor platforms nailed to them. Once popular when long lumber was plentiful, balloon framing has been largely replaced by platform framing. However, balloon framing is growing in popularity again in light-gauge, steel-stud construction. For light-gauge steel, long framing members

are not as much of an issue. Some electricians prefer working in balloon-frame buildings because the lack of fire blocking makes it much easier to add circuits.

Home inspectors should be able to explain that, in balloon framing, there exist chases for fire to quickly travel from floor to floor. This hazard can be mitigated by the use of firestops at each floor level, but firestops can't always be confirmed by home inspectors. Balloon framing has been outlawed by building codes in many areas because of the fire danger that it poses. Again, this can be mitigated by adding firestops.

The home inspector might notice a down-slope in the floor toward central walls caused by the differential shrinkage of the wood framing members at the perimeter.

Platform Framing

In platform framing, the joists comprise any number of individual floors or platforms that wall framing components are constructed on top of—hence, the term platform framing.

Platform framing is the most common method of frame construction. The floor, or platform, is made up of joists that sit on supporting walls, beams or girders, and covered with a plywood or OSB sub-floor. In the past, 1x planks set at 45 degrees to the joists were used for the sub-floor.

Floor joists can be engineered lumber trusses or I-beams that have increased rigidity and longer spans, with the added benefit of conserving natural resources. They allow easier access for runs of plumbing, HVAC, etc.

Inspector Safety

The structural part of a home inspection is the most dangerous. Here are some tips that will help keep you safe on the job.

Ladder Safety

You are not required to walk the roof in order to perform a complete home inspection. If you are using a ladder on your inspection, choose a location that is well away from all power lines. Coming into contact with live wires can be fatal. If you transport your ladder on the roof of your vehicle, the ladder may become wet, so dry off the rungs before climbing it. Place the ladder on level ground and open it completely, making sure all locks are engaged. Read telescopic ladder instructions carefully. Use the “4-to-1 Rule” for extension ladders, which states that for each 4 feet of distance between the ground and the upper point of contact (such as the roof), move the base of the ladder out 1 foot. Always face the ladder when climbing, and wear slip-resistant, rubber-soled shoes. Keep your body centered on the ladder and gauge your safety by your belt buckle. If your buckle passes beyond the ladder rail, you are over-reaching and at risk of falling. Stand at or below the highest safe standing level on a ladder. For a step ladder, the safe standing level is the second rung from the top, and for an extension ladder, it's the fourth rung from the top.

Attic Safety

Risks of inspecting a roof attic include: falling through the floor (or the ceiling of the level below); bumping your head on rafters or collar ties; breathing insulation dust; and coming into accidental contact with exposed wiring. Be conscious of these risks while inspecting an attic.

Crawlspace Safety

Crawlspaces pose the riskiest part of a home inspection. Dangers include: bumping your head; breathing insulation dust; exposure to rodents and their droppings (which can lead to illness); exposure to mold; cutting yourself on sharp duct edges; touching exposed wiring; and contact with snakes, spiders, and even wild animals. It is unwise to inspect a crawlspace without letting someone know of your location. Never enter a crawlspace that has standing water in it.

Quiz #1

1. The "4-to-1 Rule" for ladder safety states that for every 4 feet of distance between the ground and the upper point of contact with the ladder, move the base out _____.
 - 1 foot
 - 2 feet
 - 4 feet


2. T/F: Balloon framing is the latest style of framing.
 - True
 - False

3. In the U.S., full basements are popular in the _____.
 - South
 - North

Answer Key is on page 36.

What to Look for Outside

Property Lot



Steep Slope

A home inspector should note if a home is on a steep slope and, therefore, subject to erosion or movement. The maximum slope of a lot is roughly 1-in-2.


Negative Grading

A home inspector should note if a home is subject to negative grading or poor drainage. Water penetration could damage the foundation over time. Also, take note of driveways that slope toward the home.

High Grading

Wood siding and sill plates should be at least 6 inches above grade. Rotten sills will be crushed by the weight of the home and lead to settlement. Furthermore, a rotten sill weakens the anchoring of the framing to the foundation.

Moisture Intrusion - Downspout



Downspouts Discharging Near the Foundation


A home inspector should note if the downspouts for the guttering system are discharging too near the foundation.

Nearby Vegetation

A home inspector should note the existence of any trees near the home.

Plants growing next to a house could raise the soil level too high against the foundation.

FOUNDATION FAILURE: TREE ROOT




Exterior

Home inspectors should look for and note:

- mortar joint condition;
- loose bricks;
- misdirected downspouts;
- overflowing gutters;
- horizontal cracks;
- vertical cracks;
- step cracks;
- untreated wood in contact with soil;
- previous repairs;

- sagging lintels;
- missing or obstructed weep holes;
- too few weep holes; and
- missing or improperly installed flashing.

Foundation Problems - Differential Settlement



Vertical Cracks

A vertical foundation crack could be due to serious settlement if it is significantly large or shows signs of ongoing movement. If the cause is shrinkage, it is of less concern than if the cracks are a result of settlement. Vertical cracks are not caused by frost.

Diagonal Cracks

Diagonal cracks that grow in width, especially ones that are wider at the bottom than at the top, indicate settlement. Diagonal cracks over windows indicate a weak header. Diagonal cracks in a poured concrete foundation that are fairly uniform in width or are hairline-type are caused by shrinkage and, though they may allow water entry, do not constitute a structural defect.

V's Heave and Pyramids Fall

Two cracks that form a V shape indicate heaving, especially if accompanied by crushed mortar joints. Two cracks that form an upside-down V or pyramid shape indicate settlement or drooping in the middle.

Horizontal Cracks Below Grade

Horizontal cracks are not caused by settlement, yet they can still be a cause for concern. Horizontal cracking is caused by pressure on the outside of the foundation wall below grade. Most often, the cause is improper back-filling, but expansive soil and frost are also possible causes.

Horizontal cracks are often accompanied by lateral displacement, meaning that one side of the crack is pushed in (or out) further than the other side. In time, and depending on conditions, the wall may begin to bow in and even collapse.

Active Crack Indications:

- The crack has been patched and has opened up again.
- The edges of the crack in the brick are sharp, and not rounded with time.
- There is no dust or debris inside the crack.
- The wall is painted, but there is no paint inside the crack.

The longer a crack has been there, the less of a structural issue it is.

Cracks That Follow Mortar Joints

Some home inspectors think that if the crack follows the mortar joint, rather than going through the brick or block, the crack isn't a problem. This is false. Walls crack at their weakest point. If the mortar is stronger than the brick, the wall will crack through the brick.

Indications of Inward Bowing at the Top of the Foundation:

- The end of an I-beam pokes out through the wall.
- The overhang of the brick veneer is most pronounced near the middle of the wall, and then disappears at the ends. Up to a 1-inch overhang is considered acceptable.

Attached Garage

When an attached garage slab heaves or settles, it will often pull away from the home and leave cracks.

Parge Coating

Block foundation walls are often parge-coated on the exterior. This coating is a mixture of Portland cement and sand, and is applied to give a smooth and uniform appearance to the foundation's exterior. Often, moisture gets behind this parge coating. In the winter through freeze and thaw cycles, the moisture pushes outward at the coating, causing it to crack and crumble. This should be noted by the inspector.


Weep Holes

Weep holes should exist at least every 36 inches.

Decks and Porches

Home inspectors should take note of:

- who built it;
- missing or loose fasteners;
- the condition of fasteners;
- a lack of fastener nails;
- the use of untreated wood;
- whether the deck is pulling away from the house;
- wobbly rails or unsound steps; and
- rot, especially where cantilevered joists penetrate the wall.



The image above depicts a cantilevered deck. Joists should be cantilevered no more than one-quarter of the joist length or three times the joist width (nominal depth), whichever is smaller.

Decks and porches are often add-ons to the original home. Many of them have been poorly built by "weekend warrior" homeowners or handyman-type contractors. So, the first question to ask is: Who built the deck?

Rule of Thumb for Cantilevered Joists

The length of a cantilever should not exceed one-third the length of the joist (or one-sixth, in some areas).


Maximum Post Spans Between Posts									
Species Group	Post Size (in inches)	Post Height Based on Deck Area Supported Sq.Ft.							
		36	48	60	72	84	96	108	120
A	4x4	12'	12'	12'	12'	10'	10'	10'	8'
	4x6	--	--	--	--	7'	7'	6'	6'
	6x6	--	--	--	--	--	--	--	--
B	4x4	12'	12'	10'	10'	10'	8'	8'	8'
	4x6	--	--	12'	12'	12'	10'	10'	10'
	6x6	--	--	--	--	--	12'	12'	12'
C	4x4	12'	10'	10'	8'	8'	8'	6'	6'
	4x6	--	12'	12'	10'	10'	10'	8'	8'
	6x6	--	--	--	12'	12'	12'	12'	12'

Maximum Joist Spans Between Beams				
Species Group	Joist Size (in inches)	Beam Spacing, Inches O.C., Based on...		
		16" Joist Spacing	24" Joist Spacing	32" Joist Spacing
A	2x6	9' 9"	7' 11"	6' 2"
	2x8	12' 10"	10' 6"	8' 1"
	2x10	16' 5"	13' 4"	10' 4"
	2x12	19' 11"	16' 2"	12' 7"
B	2x6	8' 7"	7' 0"	5' 8"
	2x8	11' 4"	9' 3"	7' 6"
	2x10	14' 6"	11' 10"	9' 6"
	2x12	17' 6"	14' 5"	11' 6"
C	2x6	7' 9"	6' 2"	5' 0"
	2x8	10' 2"	8' 1"	6' 8"
	2x10	13' 0"	10' 4"	8' 6"
	2x12	15' 9"	12' 7"	10' 2"

Visit www.nachi.org/deck-inspections to read InterNACHI's article "Inspecting a Deck, Illustrated."

Roof

ROOFING STYLES



Home inspectors should take note of:

- sagging rafters;
- sagging roof sheathing between rafters;
- sagging or crooked ridge board;
- leaking gutters; and
- roof spreading.

Roof Sheathing Spans		
APA Rating	Thickness (in inches)	Maximum Span (in inches)
12/0	5/16	12
16/0	5/16 to 3/8	16
24/0	3/8 to 1/2	24
32/16	15/32 to 5/8	32
48/0	23/32 to 7/8	48

Quiz #2

1. The maximum slope of a lot is roughly _____.

1 in 3

1 in 2

1 in 12

1 in 10

2. Wood siding and sill plates should be at least ___ inches above grade.

2

6

18

3. T/F: V's heave and pyramids fall.

True

False

4. Deck joists that cantilever half their length are _____.

dangerous

safe

5. The _____ style of roof does not have a gable.


hip

gambrel

shed

Answer Key is on page 36.

What to Look for Inside



Roofing Structure and Attic

In an unfinished attic, the home inspector can see any number of structural framing elements, including rafters, trusses, joists, collar ties, and roof sheathing.

The home inspector should take note of:

- truss modification;
- cut rafters, especially around skylights;
- sagging rafters;
- sagging roof sheathing;
- poor ventilation;
- mold;
- roof leaks;
- sistered or repaired rafters;
- missing or broken collar ties;
- cracked or split rafters;
- evidence of past fires;
- trusses out of plumb more than $1/50^{\text{th}}$ of the height; and
- truss modifications.

Collar Ties

Collar ties connect opposing rafters and are typically placed in the top third of the attic space. Collar ties hold the rafters down against the ridge board and, to an extent, help prevent rafter spread. Home inspectors should take note of attics without collar ties, especially where the rafters run perpendicular to the joists. Collar ties must be at least 1 x 4 inches (nominal) and spaced not more than 4 feet on center.

Finished Attics

One of the biggest problems with attics is when they have been finished into a living space. Often, the floor joists are only large enough to carry the ceiling below and were never meant to support a living space above.

Poor Ventilation


Ventilation is important to prevent condensation that could lead to structural water damage. Ventilation is also important to prevent excessive heat build-up, which can warp and shrink wood. Insulation must be at least an inch away from sheathing, and must not block vents.

Rafter Spread

A lack of rafter ties can cause rafter spread, especially during heavy snows. This often occurs near the middle of the ridge board, as outside walls keep the ends of the ridge supported. Rafter spreading causes ridge sagging and can push the top parts of the walls out, especially during heavy snows.

Roof Leaks


If you discover a roof leak, try to determine the origin of the path of the water, and what structural damage it may have caused.



Basement and Crawlpace

Frost Heave: Basements


SIGNS OF FROST HEAVE DAMAGE



The home inspector should look at all visible surfaces in the basement and crawlpace and take note of:

- access opening restriction;
- dehumidifiers;
- water stains;
- efflorescence;
- paint;
- rust at the bottom of the heating system;
- crawlpace ventilation;
- standing water;
- evidence of wood-destroying organisms;
- cracks;
- treatment holes for wood-destroying organisms;
- walls that are out of plumb;
- daylight through foundation;
- piers and columns that are out of plumb;
- sagging floor joists;

- insulation vapor-barrier orientation;
- waterproofing systems;
- band joist rot;
- sill plate rot;
- untreated wood in direct contact with concrete (but note that some codes permit untreated wood to contact interior piers filled with concrete);
- standing water in the sump pit;
- exposed dirt floor in the crawlspace;
- additional jack or pier supports;
- evidence of animals;
- cold joints poured in concrete walls;
- mold or fungus;
- crumbling mortar joints;
- rusted steel columns;
- repairs;
- missing column-to-beam sealers;
- connections; and
- poor ventilation.



Check both walls and slab floors for any signs of cracking. Any cracks that are 1/4-inch wide or wider may be an indication of serious problems that require evaluation by a licensed professional engineer. Remember: The job of the inspector is to observe and report—not to analyze.

Diagonal cracks that grow in width, especially ones that are wider at the bottom than at the top, indicate settlement. Diagonal cracks over windows indicate a weak header. Diagonal cracks in a poured concrete foundation that are fairly uniform in width or are hairline-type are caused by shrinkage and, though they may allow water entry, do not constitute a structural defect.


Horizontal wall cracks are typically caused by frost, and exist at about the frost line.

Sill-plate anchor bolts should have 2-inch washers, be no closer than 7 bolt-diameters from the end of the sill, no further away than 12 inches from the end of the sill, and no fewer than two per piece of sill material.

Check the bottom of the heating system if it sits on the floor. Is it rusted? If so, there may have been flooding or standing water in the past.

If the house has been winterized and the heat has been turned off, the frost depth goes down. Unheated homes can suffer heaving.

Crawlspaces




Access openings must be a minimum of 18 inches high by 24 inches wide.

Where physical entry is impossible, use a powerful flashlight. A digital camera with a zoom lens works well.

Fiberglass batt insulation should have the vapor barrier facing the heated side. Often, the paper (kraft) facing or foil facing can be seen from below. Many homeowners install it this way because it looks neater or because they want to protect themselves from the raw fiberglass material.

Frost heave may occur during the winter after crawlspace walls are insulated because the lack of insulation was keeping the soil near the building warm enough to prevent freezing.

INSUFFICIENT BEAM SUPPORT



The grade (soil) should be at least 18 inches below the bottom of the floor joists, and 12 inches below beams. However, some codes require 24 inches below the bottom of the floor joists and 18 inches below the beams so that inspectors and contractors can enter. Most codes require 18-inch-high access openings. So, if a beam is lower than that, the inspector should note it in his report as a restriction. Columns and posts must be constrained to their footings, must be a minimum of 4x4, must be connected to girders with approved hardware, and be pressure-treated if closer than 8 inches to the soil.

Piers made of hollow concrete block or cinder block should be installed with the hollow channels set vertically.


There should be at least two vents to the outside in enclosed areas, such as crawlspaces (outside the heated envelope of the home), and at least one vent for every 300 square feet of floor area.

Crawlspace Safety

Be especially careful if access to the crawlspace area is from the exterior. Animals can be living inside, including raccoons, snakes and rats. It is not advisable to enter any crawlspace area that is wet or where standing water can be seen. Pay close attention to electrical wiring, and look for open junction boxes. Use extreme caution in any crawlspace where a dirt floor is all that exists, and never assume that there is dirt present under a polyethylene sheet. It could be covering a hole.

Floors


FRAMING LOAD



The home inspector should take note of:

- unlevel flooring;
- cracked tiles;
- sagging floor joists;
- evidence of wood-destroying organisms;
- treatment holes for wood-destroying organisms;
- joist or sub-floor rot;
- sistered or repaired joists;
- evidence of missing joists that should have been installed or were removed and not replaced;
- evidence of missing joists under load-bearing walls;
- cracked joists;
- signs of deflection, and a noticeable bounce to floors;
- squeaking floors;
- wood in contact with concrete;
- poor joist-end bearing;
- inappropriate notching or holes in joists;
- joist splits;
- over-spanning or under-sized joists;
- joists too close to grade (soil);
- over-spanned or under-sized sub-flooring;
- swollen wafer board or OSB sub-flooring; and/or
- crowning.

BEAM/FLOOR TRUSS TYPES



Generally speaking, it will be rare to see joists spread more than 24 inches apart, but if this condition is discovered, look for any signs of a joist that may have been removed.

In rooms where exterior covered porches may have once existed, it is not unusual to find that sleepers and a new sub-floor were installed because exterior porch floors are often pitched away from the dwelling to allow rainwater to run off and away from the home.

Home inspectors often notice a hump in the floor on either side of the beam underneath. This is generally caused by excessive joist overlap where the ends of an extra-long joist kick up. This "teeter-totter" effect also occurs with cantilevered joists when deck joists run through a wall, for example. These humps are not a serious structural problem.

Cracked tiles are usually the result of the sub-floor not being rigid enough.

General rules about standard dimensional joists:

- Double joists should be installed under parallel bearing walls.
- Maximum holes should not exceed a third of the height of a joist.
- Holes should not be within 2 inches of the top or bottom of a joist.
- No notches should appear in the middle-third of a span.

General rules about prefabricated I-joists:

- There should be no notching of either flange.
- There should be no big holes or notches in the ends of the joists.
- There should be no holes within 6 inches above a bearing wall or girder.

Cracks in Concrete Floors with Basements


The concrete floor is not an integral part of the foundation and is often poured after the home is nearly finished.

Cracks in Slab-on-Grade

It is difficult to tell if slab-on-grade cracks indicate a structural problem, so all such cracks should be noted and reported.

Wood in Contact with Concrete

Sill plates on top of concrete foundations should be made from treated wood, or have sill sealers or separators between them. Wood beams embedded into concrete foundations should be treated.



Crowns

A best practice when constructing a floor system with dimensional lumber joists is to install the boards with the crown upward. Floor joists tend to have a slight bend, referred to as a crown. Engineered floor joists do not have crowns. Many bridges have crowns. Take a look at some bridges, and you may see that many are built with a crown or a hump in the center of the bridge that is higher than the ends of the bridge. To check for a crown on a floor joist, position your nose near one end of a board and look down the lengthwise edge of the board. You just might see a slight curve in the board. Contractors will install floor joists with all of the crowns upward. Crowning floor joists in this way will help provide a consistent floor surface. After the floor decking and additional loads are installed, the weight will push down on the joist crowns and will help provide a consistent and flat floor surface.

Walls and Ceilings

The home inspector should take note of:

- bowing walls;
- cracks;
- no visible support beneath load-bearing walls;
- bulging paneling;
- waves and bows;
- walls out of plumb; and
- rusty nail heads.


The thickness of some interior walls may give the inspector clues as to how the house is constructed. For instance, if all interior walls are framed with 2x4 studs and you come across a wall framed with 2x6s, or even 2x8s, you could be looking at a plumbing wall, a load-bearing wall, or even a marriage wall between two sections of a modular home configuration.

Tiny cracks that follow the plaster surface that look like spider veins may be indicative of a moisture problem behind the plaster itself. Diagonal cracks can be associated with settlement or shifting of foundational elements. Cracks over doors and windows can be attributed to the expansion and contraction of wooden framing components and are generally not considered structural defects.

Waves and bows can be the result of the lath pulling away from wooden framing components.

Water intrusion is always a factor, so look for staining and dark areas. Mold and water stains can be an indication of long-term problems associated with faulty plumbing, or moisture intrusion from exterior walls or leaking roofs. If walls below windows look stained or are wet, check the sills of the windows above them. Look for rusty nail heads that can be seen through wallpaper.

LOAD- AND NON-LOAD BEARING WALLS



Truss Uplift

Truss uplift occurs in the winter when the bottom chord of roofing trusses arch up. Home inspectors often mistake it for settlement of central walls. Don't be fooled. Not everything settles downward. Use of a long level can reveal what is going on. There is no cure for truss uplift but it is not a structural problem.

Windows, Doors and Moldings

The home inspector should take note of:

- daylight showing through around exterior doors and windows;
- windows and doors that stick;
- large gaps at trim and molding joints;
- frame rot;
- signs of moisture;
- cracked glass;
- lock sets that no longer line up;
- door frames out of plumb;
- planed doors; and
- doors cut as the home settles.

Quiz #3

1. In a crawlspace, if the distance between the soil and the bottom of a girder is 15 inches, the inspector should _____.
 - note it in the report as restricted access
 - dig to gain access to the area on the other side of the girder
2. T/F: Truss uplift is a major structural problem.
 - True
 - False
3. In crawlspaces, the grade (soil) should be at least ___ inches below the bottom of the floor joists, and ___ inches below the beams.
 - 12.....18
 - 18.....12
4. Which roof framing members reduce rafter spread?
 - collar ties
 - ridge boards
 - cripple walls
5. The maximum size of a hole should not exceed _____ the height of the joist.
 - one-half
 - one-third

Answer Key is on page 36.

The Report

Report Writing

The home inspector should use InterNACHI's Pre-Inspection Agreement.

InterNACHI's Pre-Inspection Agreement helps protect you, and clearly explains to your client what home inspectors do and don't do, such as:

"5. INSPECTOR does not perform engineering, architectural, plumbing, or any other job function requiring an occupational license in the jurisdiction where the inspection is taking place, unless the inspector holds a valid occupational license, in which case he/she may inform the CLIENT that he/she is so licensed, and is, therefore, qualified to go beyond this basic home inspection and, for an additional fee, may perform additional inspections beyond those within the scope of the basic home inspection. Any agreement for such additional inspections shall be in a separate writing or noted here..."

The home inspector should note limitations in his/her report.

Most of a home's structure is buried underground or hidden behind walls, but the home inspector should still note limiting factors in the report. Examples include references to:

- finished basements;
- inaccessible or dangerous crawlspaces;
- beams, girders, posts and joists that may be covered, boxed in, or above ceilings;
- insulation in the joist bays;
- inaccessible rooms;
- owner's personal items that may obstruct access and visibility;
- fresh paint; and
- dogs.

The home inspector should include (or at least reference) InterNACHI's SOP in his/her report.

Here are the Limitations, Exceptions and Exclusions from InterNACHI's Standards of Practice for Performing a General Home Inspection, a copy of which should be included (or at least referenced) in every home inspection report. The highlighted sections pertain directly to the structural portion of a home inspection.

2.I. Limitations:

- I. An inspection is not technically exhaustive.
- II. An inspection will not identify concealed or latent defects.
- III. An inspection will not deal with aesthetic concerns or what could be deemed matters of taste, cosmetic defects, etc.

- IV. An inspection will not determine the suitability of the property for any use.
- V. An inspection does not determine the market value of the property or its marketability.
- VI. An inspection does not determine the insurability of the property.
- VII. An inspection does not determine the advisability or inadvisability of the purchase of the inspected property.
- VIII. An inspection does not determine the life expectancy of the property or any components or systems therein.
- IX. An inspection does not include items not permanently installed.
- X. These Standards of Practice apply only to properties with four or fewer residential units.

2.2. Exclusions:

- I. The inspector is not required to determine:
 - A. property boundary lines or encroachments.
 - B. the condition of any component or system that is not readily accessible.
 - C. the service life expectancy of any component or system.
 - D. the size, capacity, BTU, performance or efficiency of any component or system.
 - E. the cause or reason of any condition.
 - F. the cause for the need of correction, repair or replacement of any system or component.
 - G. future conditions.
 - H. compliance with codes or regulations.
 - I. the presence of evidence of rodents, birds, animals, insects, or other pests.
 - J. the presence of mold, mildew or fungus.
 - K. the presence of airborne hazards, including radon.
 - L. the air quality.
 - M. the existence of environmental hazards, including lead paint, asbestos, or toxic drywall.
 - N. the existence of electromagnetic fields.
 - O. any hazardous waste conditions.
 - P. any manufacturers' recalls or conformance with manufacturer installation, or any information included for consumer protection purposes.
 - Q. acoustical properties.
 - R. correction, replacement or repair cost estimates.
 - S. estimates of the cost to operate any given system.
- II. The inspector is not required to operate:
 - A. any system that is shut down.
 - B. any system that does not function properly.

- C. or evaluate low-voltage electrical systems such as, but not limited to:
 - 1. phone lines;
 - 2. cable lines;
 - 3. satellite dishes;
 - 4. antennae;
 - 5. lights; or
 - 6. remote controls.
- D. any system that does not turn on with the use of normal operating controls.
- E. any shut-off valves or manual stop valves.
- F. any electrical disconnect or over-current protection devices.
- G. any alarm systems.
- H. moisture meters, gas detectors, or similar equipment.

III. The inspector is not required to:

- A. move any personal items or other obstructions, such as, but not limited to: throw rugs, carpeting, wall coverings, furniture, ceiling tiles, window coverings, equipment, plants, ice, debris, snow, water, dirt, pets, or anything else that might restrict the visual inspection.
- B. dismantle, open or uncover any system or component.
- C. enter or access any area that may, in the opinion of the inspector, be unsafe.
- D. enter crawlspaces or other areas that may be unsafe or not readily accessible.
- E. inspect underground items, such as, but not limited to: lawn-irrigation systems; or underground storage tanks (or indications of their presence), whether abandoned or actively used.
- F. do anything which may, in the inspector's opinion, be unsafe or dangerous to the inspector or others, or damage property, such as, but not limited to: walking on roof surfaces, climbing ladders, entering attic spaces, or negotiating with pets.
- G. inspect decorative items.
- H. inspect common elements or areas in multi-unit housing.
 - I. inspect intercoms, speaker systems, or security systems.
 - J. offer guarantees or warranties.
 - K. offer or perform any engineering services.
 - L. offer or perform any trade or professional service other than general home inspection.
- M. research the history of the property, or report on its potential for alteration, modification, extendibility or suitability for a specific or proposed use for occupancy.
- N. determine the age of construction or installation of any system, structure or component of a building, or differentiate between original construction and subsequent additions, improvements, renovations or replacements.

- O. determine the insurability of a property.
- P. perform or offer Phase I or environmental audits.
- Q. inspect any system or component that is not included in these Standards.

The Standards can be read online in their entirety at www.nachi.org/sop

Conclusion

Performing the structural portion of a home inspection on a finished and occupied dwelling is a daunting task. Time limitations are a reality during any home inspection. Furniture, insulation, clutter, and stored items all present potential limitations on access and inspection. Lighting, painted surfaces and edges can play tricks on the inspector's eyes. Distractions, fatigue and stress can all take their toll.

Throughout the home inspection, try to keep conscious of the fact that almost everything you observe provides information about the home's structural integrity. A holistic approach to performing home inspections is always best.

Appendix I: Answer Keys

Answer Key to Quiz #1

1. The "4-to-1 Rule" for ladder safety states that for every 4 feet of distance between the ground and the upper point of contact with the ladder, move the base out 1 foot.
2. T/F: Balloon framing is the latest style of framing.
Answer: False
3. In the U.S., full basements are popular in the North.

Answer Key to Quiz #2

1. The maximum slope of a lot is roughly 1 in 2.
2. Wood siding and sill plates should be at least 6 inches above grade.
3. T/F: V's heave and pyramids fall. Answer: True
4. Deck joists that cantilever half their length are dangerous.
5. The hip style of roof does not have a gable.

Answer Key to Quiz #3

1. In a crawlspace, if the distance between the soil and the bottom of a girder is 15 inches, the inspector should note it in the report as restricted access.
2. T/F: Truss uplift is a major structural problem.
Answer: False
3. In crawlspaces, the grade (soil) should be at least 18 inches below the bottom of the floor joists, and 12 inches below the beams.
4. Which roof framing members reduce rafter spread?
Answer: collar ties
5. The maximum size of a hole should not exceed one-third the height of the joist.

EDUCATION & TRAINING BOOKS

Whether you're new to the business, an inspector seeking more information, or a veteran of the industry looking to expand your knowledge, these official InterNACHI publications will help you become the best inspector you can be.

We Offer the Following Education & Training Books:

- **How to Inspect the Exterior**
Item Number: 0094
- **How to Perform Deck Inspections**
Item Number: 0029
- **Residential Plumbing Overview**
Item Number: 0064
- **Inspecting HVAC Systems**
Item Number: 0061
- **Safe Practices for the Home Inspector**
Item Number: 0038
- **Inspecting the Attic, Insulation, Ventilation & Interior**
Item Number: 0109
- **How to Perform Electrical Inspections**
Item Number: 0023
- **How to Inspect Pools & Spas**
Item Number: 0076
- **How to Perform Roof Inspections**
Item Number: 0042
- **How to Perform a Mold Inspection**
Item Number: 0022
- **How to Perform Radon Inspections**
Item Number: 0028
- **Inspecting Foundation Walls and Piers**
Item Number: 0065
- **25 Standards Every Inspector Should Know**
Item Number: 0037
- **How to Inspect for Moisture Intrusion**
Item Number: 0073
- **International Standards of Practice for Inspecting Commercial Properties**
Item Number: 0016
- **Structural Issues for Home Inspectors**
Item Number: 0059

The purpose of these publications is to provide accurate and useful information for home inspectors in order to perform an inspection of the various systems at a residential property. They also serve as study aids for InterNACHI's online courses, as well as reference manuals for on the job.

Find these books plus more tools to grow your inspection business at
www.InspectorOutlet.com



INSPECTOR OUTLET

YOU'LL BE SHOCKED AT OUR LOW PRICES!

Inspector Outlet is your source for all things home inspection-related. We are the official store for InterNACHI publications, equipment and apparel. We strive to provide the best products at the lowest prices in the industry.



Find an outstanding selection of original training manuals, checklists, articles and PDFs, as well as publications for clients, including the best-selling home-maintenance guide, *Now That You've Had a Home Inspection*.

We offer a great line of protective outerwear and customized apparel for home inspectors, including shirts, jackets and hats.



InterNACHI's Inspector Marketing Department can design and print a variety of custom marketing materials for your home inspection business.

Protect yourself and your clients on the job with our specialized safety and inspection equipment that help make your inspections easier and safer.



Are you an InterNACHI member? Inspector Outlet offers free inspector decals and embroidered patches to all eligible members!

"Inspector Outlet is officially endorsed by InterNACHI for the best prices in the business for our members."

—Nick Gromicko, Founder of InterNACHI



INSPECTOR OUTLET

www.InspectorOutlet.com



Sales@InspectorOutlet.com